

INSTALLATION INSTRUCTIONS

QUICK START SURFACE-MOUNTED ADA DRYER


B-7120 White Panel S B-7128 Silver S




Installation Instructions Surface-Mounted Hand Dryer	Pages	2 & 3
Installation Instructions Surface-Mounted ADA Dryer	Pages	4 & 5
Electrical Requirements	Pages	6 & 7
Notes/Disclaimer	Pages	8 & 9
Important Labels and Attachments	Pages	10 & 11
#	Pages	12 & 13
Warranty	Pages	14 & 15





**WARNING: TURN ELECTRICAL POWER SUPPLY OFF BEFORE
MAKING ELECTRICAL CONNECTIONS.
DRYER MUST BE GROUNDED (EARTHED).**






**ADVERTENCIA: DESCONECTAR LA ALIMENTACI N DE RED
ANTES DE HACER LAS CONEXIONES EL CTRICAS.
EL SECADOR DEBE ESTAR CONECTADO A TIERRA.**







**HINWEIS: VOR MONTAGE NETZANSCHLU TRENNEN.
TROCKNER MUSS GEERDET WERDEN.**

















Warranty

IMPORTANT

LIMITED WARRANTY

SAVE

Installation Date: _____

Serial Number (S/N): _____

Installation Address: _____

Telephone Number: _____

Model Number: B-7120 B-7128 D _____

Garantía

Garantie

Garanzia

